

Instructions below are for cars with the steering wheel on the left side of the car (Americas, Europe and most of the world). Reverse the sides if your steering wheel is on the other side

NOTE: Monaco2 charger will work with ANY phone. As long as there is a MagSafe ring on the outside of the phone case.

- **iPhones** will naturally have a MagSafe ring on the phone, but it will **NOT** work though the case. Make sure that phone case is **ALSO** equipped with a MagSafe ring.
- **Android** phones will require a MagSafe case. There are plenty available online. Just search for your phone model+MagSafe case.

1. Align the top of the Monaco2 bracket as in the picture below and insert the blade into the seam right of the PCM (radio). Feel for the good angle. Then push all the way in. It will stop when back of the bracket is against dash
2. (Optional) Dash panels fit can vary. If you feel that mount is not rock solid when inserted all the way - apply included felt strip to the bracket tab on the side away from the PCM (radio).



3. Bend the power cable so it is not in the path of the glove box when the glove box opens.
4. Insert plastic trim tool and slightly twist it to open the gap between the side panel on the left and glove box assembly on the right.
5. Carefully work/push the flat power cable into that gap so it exits quite close to the 12V outlet.

It should go flat and straight to the 12V outlet, exactly like outlined in the pictures.



6. Insert the power adapter into the 12V outlet, and insert the power cable into the USB-C port on the adapter.

Rotate the adapter so all the extra cable is on/around the adapter and there is no slack.



TIP: to easily grab the phone from the charger - do **NOT** pull the phone straight off the holder. "Break" the hold by pulling one side (left or right) of the phone first.